



NOTES:

1. BUS STOP POLE LOCATION SHALL BE AS PER DIT BUS OPERATING GUIDELINES.
2. WARNING TACTILE INDICATORS SHALL BE OFFSET 300mm FROM FACE OF KERB.
3. NO DRIVEWAYS ARE ALLOWED IN THE BUS STOP AREA.

CoA 544 **BUS STOP TREATMENT - UNSEALED FOOTPATH**
SCALE 1:50 @ A3

REV	DESCRIPTION	DATE	<div>CONSTRUCTION STANDARD</div> <div>TRANSPORT</div> <div>BUS STOP TREATMENT - UNSEALED FOOTPATH</div>		<div><div><div></div></div><div>CITY OF ADELAIDE</div></div>	
A	ORIGINAL ISSUE	03/23				
B	GENERAL REVISION	04/23			SHEET NUMBER	REVISION
					TR043	B