


- NOTES:
- 1. BUS STOP POLE LOCATION SHALL BE AS PER DIT BUS OPERATING GUIDELINES.
 - 2. WARNING TACTILE INDICATORS SHALL BE OFFSET 300mm FROM FACE OF KERB.
 - 3. NO DRIVEWAYS ARE ALLOWED IN THE BUS STOP AREA.



BUS STOP TREATMENT - SEALED FOOTPATH

SCALE 1:50 @ A3

REV	DESCRIPTION	DATE	<div>CONSTRUCTION STANDARD</div> <div>TRANSPORT</div> <div>BUS STOP TREATMENT - SEALED FOOTPATH</div>		<div>CITY OF ADELAIDE</div>	SHEET NUMBER	REVISION
A	ORIGINAL ISSUE	12/22					